Heat Sink Mounting System

The new HSCB engineered mounting system provides secure attachment of a heat sink to the circuit board while providing firm contact to the chip component allowing optimum heat dissipation. The three-piece fastening system,

sold individually, includes the screw, spring and receptacle nut. The clamp load created is determined by the spring rate and the amount of deflection that is designed into the joint of the hardware. The system also allows for slight expansion and contraction of the joint components without stress to the delicate circuitry. The unique "click" feature lets the user know when the fastener is completely installed.



- Screw can not be overtightened. Audible "click" when fully engaged.
- Screw and spring mount together permanently into the heat sink.
- Spring determines clamp force.
- Receptacle nut mounts permanently to the PC board.
- Provides even, constant contact of heat sink to chip component.
- Allows removal of heat sink if desired.



To select proper length code of nut/standoff:

- 1) Determine "G", the distance from the top surface of the heat sink to the top of the P.C. Board.
- Find the combination of Screw (HSCB) and Nut (HSR) whose sum of Screw Factor (SF) plus Nut Factor (NF) are closest to G.
- 3) Find D = G SF NF. The D value must be a negative number between zero and 1mm or 1/32" (1 dash length of HSR nut).
- 4) The actual working load is equal to the Spring (HSL) Working Load
 + (D x spring rate k). Lower D value results in lower force.

If this or any standard product does not meet your application needs, contact our PEM Technical Support group at techsupport@pemnet.com to develop a special product that matches your specific application.

Threads:

TYPE HSCB[™] SELF-CAPTIVATING SCREW



All	dimensions	are in	inches.
	annononono	u. o	

Material: Hardened carbon steel
Finish: Screw - ZI - Zinc plated, 5µm, colorless (2)
For use in sheet hardness: HRB 80 / HB150 or less ⁽³⁾

External, ASME B1.1, 2A / ASME B1.13M, 6g (1)

PART NUMBER DESIGNATION



ED	Thread Size	Туре	Thread Code	Length Code "L" ±.015 .320	Min. Sheet Thickness	Hole Size in Sheet +.003000	Es ±.010	Hı Ref.	H2 Ref.	Ts Min.	Screw Factor (SF)	Driver Size	Min. Dist Hole ¢ To Edge
NIFI	.112-40 (#4-40)	HSCB	440	4	.040	.112	.312	.300	.470	.130	.170	#1	.156
)	.138-32 (#6-32)	HSCB	632	4	.040	.138	.352	.300	.470	.130	.170	#2	.178

All dimensions are in millimeters.

ואוכ	Thread Size x Pitch	Туре	Thread Code	Length Code "L" ±0.4 8.13	Min. Sheet Thickness	Hole Size in Sheet +0.08	Es ±0.25	Hı Ref.	H2 Ref.	Ts Min.	Screw Factor (SF)	Driver Size	Min. Dist Hole © To Edge
Σ	M3 x 0.5	HSCB	M3	3	1	3	8.18	7.67	12	3.3	4.32	#1	4.13

NOTE: HSCB screws, HSR nuts and HSL springs are sold separately.

(1) As with all Class 2A/6g external threads with an additive finish, the maximum major and pitch, after plating, may equal basic sizes and be gauged to Class 3A/4h, per ANSI B1.1, Section 8, Table 3A and ANSI B1.13M, Section 8, Paragraph 8.2.

(2) See PEM Technical Support section of our web site (www.pemnet.com) for related plating standards and specifications.





TYPE HSR[™] BROACHING NUT/STANDOFF



Threads: Internal, ASME B1.1, 2B / ASME B1.13M, 6H Material: Carbon steel Finish: ET - Electro-plated tin ASTM B 545, class B with clear preservative coating, annealed ⁽¹⁾ For use in sheet hardness: HRB 60 / HB 107 or less ⁽²⁾ PART NUMBER DESIGNATION HSR - 440 - 2 ET



Туре

Length Finish Code Code

All dimensions are in inches.

ED	Thread Size	Туре	Thread Code	Length Code	A (Shank) Max.	Min. Sheet Thickness	Hole Size In Sheet +.003000	C ±.003	ы ±.005	F ±.010	TN ±.005	Nut Factor (NF)	Min. Dist. Hole © To Edge
ц.	.112-40	ЦСР	440	2	060	060	166	19/	210	080	.065	.000	0.17
z	(#4-40)	non	440	3	.000	.000	.100	.104	.215	.000	.093	.031	0.17
	.138-32	цер	622	2	060	060	010	221	201	060	.065	.000	0.22
	(#6-32)	non	ISR 632 —	3	.000	.000	.213	.231	.201	.000	.093	.031	0.22

All dimensions are in millimeters.

TRIC	Thread Size x Pitch	Туре	Thread Code	Length Code	A (Shank) Max.	Min. Sheet Thickness	Hole Size In Sheet +0.08	C ±0.08	En ±0.13	F ±0.25	T⊾ ±0.13	Nut Factor (NF)	Min. Dist. Hole © To Edge
ΞV	M3 x 0.5	HCB	M3	2	153	153	1 22	4.68	5 5 6	13	2	.75	11
2	WI3 X 0.3	non	WIJ	3	1.55	1.00	7.22	4.00	5.50	1.0	3	1.75	т. т

NOTE: HSCB screws, HSR nuts and HSL springs are sold separately.

See PEM Technical Support section of our web site (www.pemnet.com) for related plating standards and specifications.
 HRB - Hardness Rockwell "B" Scale. HB - Hardness Brinell.

TYPE HSL[™] SPRINGS

HSL springs are engineered to provide a reliable and repeatable spring rate when assembled with mating PEM hardware. The spring rate is critical to the successful assembly of your heat sink. Clamp load will be determined by the spring rate and deflection that is designed into the joint.

Part	Mini Insid	mum e Dia.	Loa Working H	ad at leight ±10%	Working Height Ref.		Spring Rate k		Spring
Number	(in.)	(mm)	(lbs.)	(N)	(in.)	(mm)	(lb/in)	(N/mm)	Material
HSL-574-35	.226	5.74	7.87	35	.270	6.86	74	12.96	17-7 Stainless Steel, Natural Finish
HSL-701-35	.276	7.01	7.87	35	.270	6.86	39	6.84	17-7 Stainless Steel, Natural Finish

NOTE: HSCB screws, HSR nuts and HSL springs are sold separately. HSL-574-35 spring fits screw thread sizes #4-40 and M3 and HSL-701-35 spring fits screw thread size #6-32.

The HSL **Inside Diameter Code** is expressed in hundredths of millimeters. Example "574" indicates a minimum inside diameter of 5.74mm or .226".

The HSL **Load Code** is expressed in Newtons developed at the working height of the spring once the joint is assembled.

Example "35" indicates working load of 35 Newtons, or approximately 8 lbs.

For designs requiring a specific spring rate, contact our PEM Technical Support group at techsupport@pemnet.com



PART NUMBER DESIGNATION



Heat Sink Mounting System

INSTALLATION

Type HSCB fastener into heat sink

- 1. Prepare properly sized mounting hole in heat sink. Do not perform any secondary operations such as deburring. If the hole is punched, be sure to install the fastener into the punch side of the hole.
- 2. Place the head of the screw into the recess of the installation anvil.
- **3.** Place the spring over the shoulder of the screw, maintaining concentricity.
- 4. Position the heat sink mounting hole over the screw.
- 5. Bring the heat sink down over the screw and onto the shoulder of the screw.
- 6. With the punch and anvil surfaces parallel, apply a squeezing force to the heat sink and the head of the screw. The squeezing action forces the displacer of the screw into the heat sink, causing it to reduce the mounting hole diameter and captivate the screw and spring.

PEMSERTER® Installation Tooling For HSCB Screw

D	Thread	Installation Tooling D	imensions (in.)	Anvil	Punch
-	Code	C	J	Part Number	Part Number
	440	.113116	.322324	8018043	970200006300
	632	.139142	.362364	8018044	970200007300
0	Thursd	Landa Hadian Taalim Di		A	Durah

O Threa	ad Installation Tooling D	imensions (mm)	Anvil	Punch
E Code	e C	J	Part Number	Part Number
M3	3.03 - 3.11	8.43 - 8.48	801845	970200229300
≥ M3	3.03 - 3.11	8.43 - 8.48	801845	97020022



Type HSR nut/standoff

- **1.** Prepare properly sized mounting hole in board.
- 2. Place fastener into the anvil hole and place the mounting hole over the shank of the fastener as shown in drawing.
- 3. With installation punch and anvil surfaces parallel, apply squeezing force until shoulder contacts the board.

0		Anvil Dimensio	ons (in.)			
FIEI	Thread Code	A	P ±.005	Anvil Part Number	Punch Part Number	
N	HSR-440	.228231	.115	975200846300	975200048	
	HSR-632	.290293	.115	975200849300	975200048	

PEMSERTER® Installation Tooling For HSR Nut

C		Anvil Dimensior	ns (mm)		
TR	Thread Code	A	P ±0.13	Anvil Part Number	Punch Part Number
M	HSR-M3	5.8 - 5.86	2.92	975200846300	975200048



Final assembly

Once the screw and spring are captivated, assemble the heat sink to the circuit board by tightening the screw into the receptacle nut or standoff until the audible "click" is heard. The screw will continue to rotate, but will no longer be engaged in the threads or continue to actively tighten.



PERFORMANCE DATA⁽¹⁾

Type HSCB (screw)

				Test Sheet Mater	al		
۵	Turno	Thread	Alum	inum	Cold-rolled Steel		
IFIE	Туре	Code	Installation (lbs.)	Pushout (lbs.)	Installation (Ibs.)	Pushout (Ibs.)	
	HSCB	440	1900	60	2600	80	
	HSCB	632	2000	90	3500	120	

METRIC	Туре	Thread Code	Test Sheet Material			
			Aluminum		Cold-rolled Steel	
			Installation (kN)	Pushout (N)	Installation (kN)	Pushout (N)
	HSCB	M3	8	265	12	355

Type HSR (nut)

	Туре	Thread Code	Test Sheet Material		
FIED			.060" FR-4 Panel		
			Installation (lbs.)	Pushout (lbs.)	
z N	HSR	440	400	65	
	HSR	632	500	80	

METRIC	Туре	Thread Code	Test Sheet Material		
			1.5mm FR-4 Panel		
			Installation (kN)	Pushout (N)	
	HSR	M3	2.2	290	

(1) Published installation forces are for general reference. Actual set-up and confirmation of complete installation should be made by observing proper seating of fastener as described in the installation steps. Other performance values reported are averages when all proper installation parameters and procedures are followed. Variations in mounting hole size, sheet material, and installation procedure may affect performance. Performance testing this product in your application is recommended. We will be happy to provide technical assistance and/or samples for this purpose.

(2) Torque values shown will produce a preload of 70% minimum tensile (125 ksi / 935 MPa) with nut factor "k" equal to .1

VALUE-ADDED CAPABILITIES







All PEM[®] products meet our stringent quality standards. If you require additional industry or other specific quality certifications, special procedures and/or part numbers are required. Please contact your local sales office or representative for further information.

Regulatory compliance information is available in Technical Support section of our website. Specifications subject to change without notice. See our website for the most current version of this bulletin.

PennEngineering®



 North America:
 Danboro, PA USA • E-mail: info@pemnet.com • Tel: +1-215-766-8853 • Fax: +1-215-766-0143 • 800-237-4736 (USA Only)

 Europe:
 Galway, Ireland • E-mail: europe@pemnet.com • Tel: +353-91-751714 • Fax: +353-91-753541

 Asia/Pacific:
 Singapore • E-mail: singapore@pemnet.com • Tel: +65-6-745-0660 • Fax: +65-6-745-2400

 Shanghai,
 China • E-mail: china@pemnet.com • Tel: +86-21-5868-3688 • Fax: +86-21-5868-3988

Visit our PEMNET™ Resource Center at www.pemnet.com

Technical support e-mail: techsupport@pemnet.com